



Case SV185 / New Holland L220, L318, L320, L321

Front & Rear Fender Installation Instructions

Hardware Included: M16-2.0 Stainless Jam Nuts (16); Tube of Blue Thread Locker (2).

Safety First: Park machine on a flat, level surface. Safely support machine before beginning installation.

1. Remove tires.
2. DO NOT remove any factory axle nuts. There is enough stud length beyond the factory nut for fender installation.
3. Apply supplied Blue Thread Lock onto the 4 referenced stud threads.
4. Slide fender onto those studs.
5. Thread on supplied jam nuts on axle hub studs and tighten firmly.
6. Reinstall tires.
7. Verify proper fender clearance.

