



Case SV280, SV340 / New Holland L328, L334

Front Fender Installation Instructions

Hardware Included: M16 x 2.0mm Coupler Nuts (8); 5/8" Flat Washers (8); M16 x 30mm Bolts (8); Split Lock Washers (8).

Safety First: Park machine on a flat, level surface. Safely support machine before beginning installation.

1. Remove tires.
2. Remove needed factory axle hub flange nuts (4 nuts per axle hub assembly). Refer to D-Fenders to determine correct ones.
3. Apply anti-seize to axle studs and supplied bolts.

Note: Apply anti-seize with the understanding that it will impact torque requirements. Adjust accordingly.

4. Slide supplied flat washer onto axle studs.
5. Thread on supplied coupler nuts on axle studs and tighten to manufacturer's torque spec.

**** Contact Dealership for Correct Torque Specs****

6. Hold fender up to coupler nuts and thread in the bolts with lock washer and tighten firmly with wrench.
7. Reinstall tires.
8. Verify proper fender clearance.

