



Case SV280, SV340 / New Holland L328, L334

Rear Fender Installation Instructions

Hardware Included: M16 x 2.0 Jam Nuts (8); 5/8" Flat Washers (8).

Safety First: Park machine on a flat, level surface. Safely support machine before beginning installation.

1. Remove tires.
2. Remove needed factory axle hub flange nuts (4 nuts per axle hub assembly). Refer to D-Fenders to determine correct ones.
3. Apply anti-seize to axle studs.

Note: Apply anti-seize with the understanding that it will impact torque requirements. Adjust accordingly.

4. Slide supplied flat washer onto axle studs.
5. Thread on supplied jam nuts on axle studs and tighten to manufacturer's torque spec.

**** Contact Dealership for Correct Torque Specs ****

6. Install fender onto axle studs. Then thread on the manufacturer's flange nuts and tighten firmly with wrench.
7. Reinstall tires.
8. Verify proper fender clearance.

