



Caterpillar 226 / 232

Front & Rear Fender Installation Instructions

Hardware Included: No Hardware Needed.

Safety First: Park machine on a flat, level surface. Safely support machine before beginning installation.

1. Remove tires.
2. Remove only the needed factory axle nuts (4 nuts per axle hub assembly).
3. Leave factory flat washer in place.
4. Apply anti-seize to axle studs.
Note: Apply anti-seize with the understanding that it will impact torque requirements. Adjust accordingly.
5. Slide fender onto axle studs.
6. Reinstall factory axle nuts and tighten to factory torque spec.
**** Contact Dealership for Correct Torque Specs****
7. Reinstall tires.
8. Verify proper fender clearance.

