



Caterpillar 236 / 242

Front & Rear Fender Installation Instructions

Hardware Included: 9/16-18 Grade 8 Zinc Nut (16); 9/16" Thick Flat Washer (16).

Safety First: Park machine on a flat, level surface. Safely support machine before beginning installation.

1. Remove tires.
2. Remove only the needed factory axle nuts & flat washers (4 nuts & washer per axle hub assembly).
3. Apply anti-seize to axle studs.

Note: Apply anti-seize with the understanding that it will impact torque requirements. Adjust accordingly.

4. Install supplied flat washer and nut. Tighten to factory axle stud torque spec.

**** Contact Dealership for Correct Torque Specs****

5. Slide fender onto the remaining exposed length of the studs.
6. While holding fender in place, thread on the factory nut onto the remaining stud length. Tighten firmly with wrench.
7. Reinstall tires.
8. Verify proper fender clearance.

