



Caterpillar 250, 260, 262, 270, 272

Front & Rear Fender Installation Instructions

Hardware Included: 9/16-18 Coupler Nuts (16); 9/16-18 x 1.25" Bolts (16); 9/16" Split Lock Washers (16).

Safety First: Park machine on a flat, level surface. Safely support machine before beginning installation.

1. Remove tires.
2. Remove only the needed factory axle nuts (4 nuts & washer per axle hub assembly).
3. **DO NOT** remove the factory flat washers.
4. Apply anti-seize to axle studs.

Note: Apply anti-seize with the understanding that it will impact torque requirements. Adjust accordingly.

5. Install supplied coupling nut. Tighten to factory axle stud torque spec.

**** Contact Dealership for Correct Torque Specs****

6. Prep for next step by applying anti-seize to supplied bolts with split washer.
7. While holding fender in place, thread on the supplied bolt with split washer into the coupler through the fender. Tighten firmly with wrench.
8. Reinstall tires.
9. Verify proper fender clearance.

