



Gehl R135 / Manitou 1350R

Front & Rear Fender Installation Instructions

Hardware Included: ¾-10 Jam Nuts (16), Tube of Blue Thread Locker (2).

Safety First: Park machine on a flat, level surface. Safely support machine before beginning installation.

1. Remove tires.
2. **DO NOT** remove any nuts from the factory axle hub assembly. The extra stud length beyond the factory nuts will be sufficient for D-Fender's installation.
3. Identify the 4 studs per axle needed for mounting the D-Fender. Clean excess paint from threads.
Note: Use a ¾-10 die or wire brush.
4. Now that the studs are relatively clean, add the supplied Blue Loctite to the studs.
5. Slide the D-Fender onto the axle hub assembly and install the supplied stainless jam nuts. Tighten firmly with wrench.
6. Reinstall tires.
7. Verify proper fender clearance.

