



Hyundai HS120V

Front & Rear Fender Installation Instructions

Hardware Included: M16-1.5mm Hex Nuts (32); 5/8" Flat Washer (16).

Safety First: Park machine on a flat, level surface. Safely support machine before beginning installation.

1. Remove tires.
2. Remove only 4 of the 8 factory axle SEMS nuts.

****Retain and store these somewhere safe. They will not be reinstalled with the fenders.****

3. Apply anti-seize to axle studs.

Note: Apply anti-seize with the understanding that it will impact torque requirements. Adjust accordingly.

4. Install supplied nuts and flat washers. Tighten to factory axle stud torque spec.

**** Contact Dealership for Correct Torque Specs****

5. Slide fender onto the remaining exposed length of the studs.
6. While holding fender in place, thread on another supplied nut onto the remaining stud length. Tighten firmly with wrench.
7. Reinstall tires.
8. Verify proper fender clearance.

