



JCB 270

Front & Rear Fender Installation Instructions

Hardware Included: No Hardware needed.

Safety First: Park machine on a flat, level surface. Safely support machine before beginning installation.

1. Lift machine in a manner that will allow the tire removal and to have the chain case oil flow/pitch away from each axle as you proceed with each fender installation.

**** This is required because JCB utilizes bolts that thread into the chain case. And when the lowest needed bolts are removed, if the machine hasn't been lifted properly, chain case oil can drain out during installation. ****

2. Remove each tire as needed.
3. Remove only needed factory axle bolts and flat washers. (4 Bolts/washers per axle hub assembly). Refer to D-Fenders to determine correct ones.
4. Prepare the bolts for next step by applying blue Loctite as seen in the 2nd image.
5. Hold fender in place and thread the factory bolt with washer through fender and axle into chain case.
6. Tighten to factory axle bolt spec.

**** Contact Dealership for Correct Torque Specs And Recommended loctite****

7. Reinstall tires.
8. Verify proper fender clearance.

